

Verlegehinweise

Laying instructions



Starke Verbindung
Kluge Technik
Strong contacts
Clever technology

Einsatzbereich:

Diese Profile eignen sich für den Abschluss aller Bodenbeläge. Individuell in der Belagstärke lassen sich diese Profile an Terrassen- und Balkontüren einsetzen. Außerdem bietet sich dieses Profil an, wenn ein Abschluss in schwer zugänglichen Nischen hinter Heizkörpern montiert werden muss. Weitere Einsatzbereiche sind Küchenarbeitsplatten und Fensterbänke. Wandanschlussprofile sind unabhängig von der Materialstärke des Bodenbelags für schwimmende und verklebte Bodenbeläge einsetzbar.

Montage:

Wandanschlussprofile werden mit der Selbstklebeausrüstung zum Wand- oder Fensterbereich verklebt. Beachten Sie bitte, dass der Untergrund tragfähig und frei von jeglichen Trennmitteln ist. Ggf. reinigen Sie die Klebestelle mittels eines geeigneten nicht filmbildenden Reinigers ab. Unter Umständen kann ein Haftvermittler notwendig sein. Nachdem Sie das Profil passend zugeschnitten haben, trennen Sie das Schutzpapier von der Selbstklebeausrüstung ab und positionieren das Profil an seinem Bestimmungsort. Mit leichtem Druck legen Sie nun das Profil an der Wand oder Terrassentür an. Drücken Sie das Profil zur endgültigen Befestigung nun erneut fest an.

Application:

These profiles are suitable for finishings on all floor coverings. Individually in the covering thickness, these profiles can be used on terrace and balcony doors. In addition, these profiles are useful when hard-to-reach niches behind radiators must be installed. Further applications are kitchen worktops and window sills. Wall connection profiles can be used regardless of the material thickness of the floor covering.

Assembly:

Wall connection profiles are glued to the wall or window area with the self-adhesive side. Please note that the surface is stable and free from any release agents. Clean the splice with a suitable non-film-forming cleaner. Under certain circumstances, a bonding agent may be necessary. After you've cut the profile to length, detach the protective paper from the adhesive and position the profile at its destination. Apply light pressure to the profile. Press the profile firmly again for final attachment.

